

Laser Compatibility Chart (Printer Range 2006 - 08)

	FX 3	FX 7	FX 10	Cart T	EP 22	EP 25	EP 27	EP 65	Cart 703	Cart 706	Cart 701 Black	Cart 701/ 701L C	Cart 701/ 701L M	Cart 701/ 701L Y	E 16	E 30	
Laser Printers																	
LBP 800					X												
LBP 810					X												
LBP 1120					X												
LBP 1210						X											
LBP 2000								X									
LBP2900									X								
LBP3000									X								
LBP 3200							X										
LBP 5200											X	X	X	X			
Laser Multi Function																	
MF 3110							X										
MF 3220							X										
MF 3240							X										
MF4120			X														
MF4140 / 4150			X														
MF4270			X														
MF 5630							X										
MF 5650							X										
MF 5730							X										
MF 5750							X										
MF 5770							X										
MF6530										X							
MF6540PL										X							
MF6550										X							
MF6560PL										X							
MF6580PL										X							
MF8180C											X	X	X	X			
Laser Faxes																	
FAX L100			X														
FAX L120			X														
FAX L200 / L220	X																
FAX L240 / L250	X																
FAX L260i	X																
FAX L280	X																
FAX L290 / L295	X																
FAX L300	X																
FAX L350 / L360	X																
FAX L400				X													
FAX L2000 / 2000IP		X															
Faxphone L75		X															
Laserclass 510				X													
Laserclass L1060P		X															
Laserclass L2050P		X															
Personal Copiers																	

